

Setting of cartridge type

Use the mini-switches (3, 6) on the rear panel to set the P2 to MM or MC depending on the cartridge type. All switches must be in the same position. For high output MC cartridges set the P2 to "MM" position.

Adjusting the cartridge load

The P2 has two load terminals (5) where You can plug in RCA connectors with resistors or capacitors soldered in. Refer to the manual of Your cartridge to chose the correct impedance.

MM: The capacitive load of a MM-cartridge influences the reproduction of high frequencies. First find out the recommended capacitive load (see manual of cartridge). Subtract from this value 150 pF for input capacitance of the P2 and cable. Solder the resulting capacitance into the RCA plugs connected to the P2's load terminals. Use only high quality polypropylene capacitors.

MC: First find out the recommended resistive load (see manual of cartridge). Then see table below for additional resistance values to be soldered into the RCA plugs connected to the P2's load terminals. Use only high quality metal film resistors.

Total load	resistor	Total load	resistor
1000	none	75	81
500	1000	50	53
300	429	30	31
150	176	20	20
100	111	10	10

Technical data P2

	MM	MC
Sensitivity	1,5 mV	180µV
Input impedance	47 kOhms/47 pF	1 kOhm / 1 nF
S/N ratio	79 dB /85 dB(A)	74 dB / 80 dB(A)
Frequency response	30 Hz – 20 kHz +/- 0,3 dB (RIAA curve)	
Power supply	230V / 50 Hz / 3VA (AC adaptor)	
Dimensions	145 x 48 x 70 mm	
Weight	0,3 Kgs	

Issued: 12/2007. Changes reserved without notice

Operating instructions

Phono pre-preamplifier /equalizer P2



AVM Next Generation GmbH, Daimlerstraße 8, 76316 Malsch

Dear customer,

thank You for purchasing this AVM product. You own now a versatile, excellent sounding hi-fi component. Before enjoying music, please read this manual carefully. After that You will know how to use your new AVM component in the optimal way.

Sincerely Yours

Your AVM-Team

Declaration of conformity (for EC only)

We herewith confirm, that the unit to which this manual belongs fulfills the EC rules necessary to obtain the sign




the necessary measurements were taken with positive results.



AVM Next Generation Audio Technologies GmbH,
Daimlerstraße 8, D-76316 Malsch
Website: www.avm-audio.com, E-mail: info@avm-audio.com

Rear Panel



- | | |
|----------------------------------|---------------------------------|
| 1 power supply connector | 5 load terminals |
| 2 audio output | 6 MM / MC-selector left channel |
| 3 MM / MC-selector right channel | 7 ground connector |
| 4 audio input from cartridge | |

Power supply

insert the supply plug of the AC adapter into the power supply connector (1). Connect the AC adapter to the mains outlet. Use only the original AC adapter, other adapters can damage the unit.

CAUTION: In case of thunderstorm or if You leave the house for a longer time we recommend that You disconnect the unit from mains.

Connection to hi-fi set

NOTE: We recommend that You disconnect mains before You make the connections.

Turntable: Connect the right and left channel of the turntable's output to the corresponding audio inputs (4) of the P2. Connect the grounding cable of the turntable or tone arm to the ground connector (7) of the P2

Amplifier: Connect the audio output (2) of the P2 to any high level input of Your amplifier. Do NOT use the phono input because the P2 already amplifies and equalizes the cartridge signal to a high level signal.